



Pet Tracker



Please read the Quick Use Guide carefully before use.



Product specifications



Scan to download the app



User manual




Smart pet ID tag

Before using this product, please scan the QR code on the product to register your pet's information as well as your contact information. In case your pet forgets the way home, kind people will scan this QR code and tell you to find your pet.



Operation

1. Pull out the battery insulator, and then the device will be turned on immediately.




2. Download and install the **Jimi Life** App from the App Store (iOS devices) or Google Play (Android devices).

3. Open the "**Jimi Life**" app and follow the steps below to register and log in to the app.



Add Your Device




- 1. Open the "**Jimi Life**" App, select the corresponding product and scan the QR code on the back of the Tracker.
- 2. Change the device name: Tap Settings-Device-select your device to edit the device name, or you can choose an emoticon for your device.


Battery	210mAh CR2032 disposable button cell battery
Service life	Up to 10 months
Buzzer	80dB
IP rating	IP65
Operating temperature	0°C to 60°C
Working Voltage	3V
Device size	9.2mm * Φ 38mm
Device weight	12g

Battery replacement operation

1. The unit uses a CR2032 battery.
2. Please use a pry bar or other tools to separate the upper and lower cover through the grooves on the top.
3. Choose the battery purchased from a regular supplier and insert it in the direction indicated by the arrow on the mainboard.



a



b



Note: Please do not immerse the battery in water or put it into fire, please do not destroy or force open the battery, the battery is disposable and does not support charging. To protect the environment, please recycle the used battery.



WARNING

KEEP OUT OF REACH
OF CHILDREN

Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.

Important reminders



1. Battery life time varies depending on individual usage habits. Frequent audible searching will accelerate the consumption of the battery.
2. In order to ensure better dustproof and waterproof, after installation, please be sure to press the upper and lower covers to ensure that the equipment is sealed.
3. Because the device adopts a crowdsourcing network, there may be a delay in positionings, such as the management platform and APP no you can wait half an hour to refresh the location information. And try to open the device in the place where there are more cell phones.
4. Please do not disassemble the device, improper handling by non-professionals may cause damage to the device.

FAQ

1. How do you confirm that the device has been turned?

The product beeps when the plastic piece is removed.

2. How do you turn off the device?

The device has low power consumption and can not be shut down; If you need to shut down the device, you need to pull out the battery.

Regulatory Safety Information



FCC Compliance Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Regulatory Safety Information

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.